

Parts List

- | | |
|------------------------------------|---------------------------------|
| 1 ea 132 WaterStone 35"Lx25"Wx12"H | 1 ea Stone Disk 11" Dia. |
| 1 ea 731-WP 120 GPH Pump | 2 ea Barbed adapters |
| 1 ea Bulkhead Fitting 1 1/8" Dia | 1 ea Rubber Grommet 1 1/8" Dia. |
| 1 ea Tubing 1/2" diameter & 4" L | 4 ea Clear Tube Spacers |


Tools Required

No Tools Required




132-WF WaterStone

INSTALLATION INSTRUCTIONS



Step 1.

Select the desired location for the water feature. Check to make sure the location is within six feet of an electrical supply and that the ground is level.



Step 2.

Remove the nut and rubber gasket from the 1 1/8" bulkhead. Insert the 1 1/8" bulkhead into the stone disk. The flange should be on the rock side of the stone disk. Slide the gasket back on and thread the nut on until hand tight.



Step 3.

Thread the barbed adaptor in to the backside of the bulkhead.

Step 4.

Slide the tubing onto the barbed adaptor.



Step 5.

Remove 731-WP pump from packaging and insert the included adaptor into the top output port on the pump.

Step 6.

Insert the adaptor on the pump into the tubing.



Step 7.

Clip the four clear tube spacers on opposing sides of the stone disk.

Step 8.

Uncoil the pump's power cord and feed the cord through the 1 1/8" diameter hole in the 132 basin. Plug the hole with the rubber gasket and feed cord through the center.



Step 9.

Set the stone disk, tubing, and pump in the basin. Make sure the 132 basin and disk are level.

Step 10.

Fill the 132 WaterStone's basin with water up to within two inches of the ledge inside the basin. Plug in the pump's power cord and water should start flowing in less than one minute. Adjust water flow to preferred volume by sliding the dial on the front of the pump. If the water is not flowing over the entire disk, level the disk until water is flowing properly.



Care & Cleaning.

- Always maintain the water level. Running the pump dry will destroy the pump.
- It is suggested to clean, treat, or change water regularly.
- Clean the 132-WF with a nylon brush using soap and hot water.
- Winter Care - Drain water from the 132-WF basin. Remove the pump, place it in a bucket of water, and store inside.



DekoRRa Products LLC
218 Highway 16
Rio, WI 53960
www.dekorraproducts.com

Telephone: 888-635-8585
920-992-6535
Fax: 920-992-6533
Email: info@dekorraproducts.com

